



# Wood Float

## Materials:

- 1 pc 2x4x8" - Handle
- 1 pc 3/4x 4 1/2 x 12" - Base
- 3 pc no. 8 wood screw, 1 1/2"

## Directions:

Cut base to dimensions, plane if needed.  
Sand.

Cut handle to dimensions. Use 1 1/2" angle to drill two holes, centered inside handle. Cut slot out with coping saw. File and sand to fit hand comfortably.

Locate pilot holes for screws centered to match handle locations.

Countersink for screws. Glue handle prior to setting screws.

